







Y3-90L-B3
Mounting diagram




Y3-90L-B5
Mounting diagram




Y3-90L-B14
Mounting diagram



Y3-90L-B34
Mounting diagram




Y3-90L-B35
Mounting diagram



Y3-90L-B14B

Mounting diagram



Y3-90L-B34B
Mounting diagram